



# Lightfry Quick Guide




Do not skip Lightfry cleanings if machine was used



4-hour cleaning cycle highly recommended.




Do not submerge door in water



Product too large or small may over/under cook



When Lightfry is up to temperature & not in use, leave basket out 4"



COOL DOWN mode needed at end of each day, do not just turn power switch off

